

# 541-12L Slip-on Bolt Kit

541-12L Rocket III Touring 08-13 Slash Cut

Comes with K&N Filter air filter # TB-2204 Use Triumph Download # 020366

Uses stock hardware

# D&D Performance Enterprises

2923 Edith lane

Ft. Worth, Texas 76117

Phone 817-834-8961

Fax 817-831-4260

## **Triumph Rocket III Touring Slip-Ons**

**541-12**

1. Remove seat and saddlebag.
2. Disconnect battery. Negative terminal first.
3. Remove stock air cleaner
4. Install new K&N air filter per supplied instructions.
5. Reinstall air box cover.
6. Remove the stock mufflers. Retain the heatshields as they will be reused.
7. Install new D&D mufflers. Make sure the supplied clamps are even with the end of the muffler.
8. Tighten rear muffler mounts.
9. Tighten clamps to 150 in.lbs.
10. Replace stock heatshields.
11. Clean mufflers with glass cleaner to remove and oil and fingerprints.
12. Reinstall saddlebags.
13. Reconnect battery.
14. Install Triumph download #020366
15. Start motorcycle and check for leaks.

**D&D Performance Enterprises**  
**2923 Edith Lane**  
**Ft. Worth, TX 76117**  
**Phone (817) 834-0996**  
**e-mail danddexhaust@email.msn.com**  
**FAX (817) 831-4260**

## Warranty on Chrome

We take every step and precaution to produce a perfect Chrome Finish. All of our Exhaust Systems are hand polished, double nickel and chrome plated. However, consistent perfect Chrome finishes are not possible without two or three hand polished copper base layers. While this may sound good it is cost prohibitive to the point of double the price or more.

In the real world, if you ride your Bike, all of this would be lost in a couple of weeks and you would be out several hundred Dollars for nothing.

All of our Systems are inspected to meet our criteria as follows:

- Visual inspection from the aspect of the System installed on the Bike. Imperfections that are visible at a few inches under fluorescent lighting disappear when standing next to your Bike.
- Specks and scratches on the bottom, inside, or anywhere they do not show are disregarded.
- Peeling chrome is a defect and is rejected.
- Discoloration in a visible area is rejected.

It is always possible for a rejectable defect to slip through inspection. We apologize if this has happened to you. Please follow these steps in order for us to process your warranty claim. Be aware that peeling chrome or a mechanical failure are the only qualifying defects after a system has been installed

1. Call or email for a RMA number; must be on carton.
2. Circle the defect with felt tip marker.
3. Package the System carefully; if it incurs shipping damage we will not be able to make a fair determination of your warranty claim.
4. Only peeling chrome or a mechanical failure will qualify for warranty after a system has been installed.

**D&D PERFORMANCE ENTERPRISES INC.**

2923 Edith Lane  
Fort Worth, TX 76117

## ONE YEAR CONDITIONAL WARRANTY

D&D Performance Enterprises Inc. backs this, and all, D&D products with a One Year Conditional Warranty under the following conditions:

- Warranty period starts at date of purchase by end-user.
- The system must have been installed using the Installation Instructions provided with this system.
- The system must not be crash-damaged; the silencer bracket must not have been moved; the system must not have been misused or improperly maintained.
- Warranty does not cover carbon fiber discoloration, or rust.
- All warranty claims must be made directly to D&D Performance Enterprises Inc. by first calling our tech line (817) 834-0996 for authorization and instructions.
- All warranty claims must be accompanied by a purchase receipt; no exceptions will be made.

**YOU MAY EXPERIENCE SOME  
DISCOLORATION DURING THE  
BREAK-IN PERIOD OF YOUR CHROME.  
IT IS IMPORTANT TO REMOVE IT WITH  
A GOOD METAL POLISH LIKE  
“SEMICHROME” AS SOON AS POSSIBLE  
UNTIL THE CHROME IS SEASONED  
AND THE DISCOLORATION NO LONGER  
APPEARS.**

---