

578-31-32 Softail 2012-2014 Bob Cat

578-31ABQ	Softail Bobcat	12-14	2:1 Black Perforated Wrapped Baffle
578-31BBQ	Softail Bobcat	12-14	2:1 Black Perforated Wrapped Baffle
578-31CBQ	Softail Bobcat	12-14	2:1 Black Perforated Wrapped Baffle
578-32ABQ	Softail Bobcat	12-14	2:1 Chrome Perforated Wrapped Baffle
578-32BBQ	Softail Bobcat	12-14	2:1 Chrome Perforated Wrapped Baffle
578-32CBQ	Softail Bobcat	12-14	2:1 Chrome Perforated Wrapped Baffle



Mounting for Muffler

1- 3/8 Flange Nut

2- Boss Exhaust Gaskets

Mounting to Frame

2- 3/8 Flat Washers

2- 3/8x16x1 Allen Head Bolts

1- Bracket

D&D Performance Enterprises

2923 Edith lane

Ft.Worth, Texas 76117

Phone 817-834-8961

Fax 817-831-4260

2012-2014 Softail “Bobcat” 2-1

578-31/32 A,B,C

1. Remove seat.
2. Remove main power fuse.
3. Disconnect O2 sensor plugs.
4. Remove stock exhaust system.
5. Remove factory O2 sensors from stock header.
6. Open box and inspect all system components (No warranty for cosmetics after pipe has been installed).
7. Install new exhaust gaskets (They are a tight fit and need to be worked in slowly).
8. Apply a small amount of Anti-Seize to the threads of the factory O2 sensors (Be careful not to get any on the end of the sensor) and install sensors in the new header.
9. Loosely install exhaust mount using supplied hardware.

10. Install header on motorcycle.
11. Loosely install factory mounting hardware.
12. Install muffler with supplied hardware.
13. Tighten hardware (To factory specifications) starting at the heads and working to the rear of the bike. Muffler clamp is to be tightened to 120 in.lbs. Check alignment as you go.
14. Reconnect O2 sensors.
15. Clean entire system with glass cleaner to remove any oil and fingerprints.
16. Install main fuse.
17. Install seat.
18. Start motorcycle and check for leaks.

Use of this system requires a tuner for proper fuel management!

D&D PERFORMANCE ENTERPRISES INC.
2923 Edith Lane
Fort Worth, TX 76117

ONE YEAR CONDITIONAL WARRANTY

D&D Performance Enterprises Inc. backs this, and all, D&D products with a One Year Conditional Warranty under the following conditions:

- **Warranty period starts at date of purchase by end-user.**
- **The system must have been installed using the Installation Instructions provided with this system.**
- **The system must not be crash-damaged; the silencer bracket must not have been moved; the system must not have been misused or improperly maintained.**
- **Warranty does not cover carbon fiber discoloration, or rust.**
- **All warranty claims must be made directly to D&D Performance Enterprises Inc. by first calling our tech line (817) 834-0996 for authorization and instructions.**
- **All warranty claims must be accompanied by a purchase receipt; no exceptions will be made.**

D&D Performance Enterprises

2923 Edith Lane

Ft. Worth, TX 76117

Phone (817) 834-0996

e-mail danddexhaust@email.msn.com

FAX (817) 831-4260

Warranty on Chrome

We take every step and precaution to produce a perfect Chrome Finish. All of our Exhaust Systems are hand polished, double nickel and chrome plated. However, consistent perfect Chrome finishes are not possible without two or three hand polished copper base layers. While this may sound good it is cost prohibitive to the point of double the price or more.

In the real world, if you ride your Bike, all of this would be lost in a couple of weeks and you would be out several hundred Dollars for nothing.

All of our Systems are inspected to meet our criteria as follows:

- Visual inspection from the aspect of the System installed on the Bike.
Imperfections that are visible at a few inches under fluorescent lighting disappear when standing next to your Bike.
- Specks and scratches on the bottom, inside, or anywhere they do not show are disregarded.
- Peeling chrome is a defect and is rejected.
- Discoloration in a visible area is rejected.

It is always possible for a rejectable defect to slip through inspection. We apologize if this has happened to you. Please follow these steps in order for us to process your warranty claim. Be aware that peeling chrome or a mechanical failure are the only qualifying defects after a system has been installed

1. Call or email for a RMA number; must be on carton.
 2. Circle the defect with felt tip marker.
 3. Package the System carefully; if it incurs shipping damage we will not be able to make a fair determination of your warranty claim.
 4. Only peeling chrome or a mechanical failure will qualify for warranty after a system has been installed.
-

**YOU MAY EXPERIENCE SOME
DISCOLORATION DURING THE
BREAK-IN PERIOD OF YOUR CHROME.
IT IS IMPORTANT TO REMOVE IT WITH
A GOOD METAL POLISH LIKE
“SEMICHROME” AS SOON AS POSSIBLE
UNTIL THE CHROME IS SEASONED
AND THE DISCOLORATION NO LONGER
APPEARS.**